

ASSEMBLING INSTRUCTIONS

CAUTION:

THIS ITEM IS MADE OF LAMINATED PARTICLE BOARD AND MEDIUM DENSITY FIBRE BOARD
TO BE ASSEMBLED ON A DRY, SOFT, SMOOTH AND CLEAN SURFACE. DO NOT USE DETERGENT OR CHEMICAL. AVOID DAMP AND SUNLIGHT.

STEP 1	CHECK YOUR HARDWARE	H6365-1A
	EURO BOLT	30 PCS
	HOUSING D-15/12.5MM	20 PCS
	HOUSING D-12/9.5MM	10 PCS
	SCREW #9 X 1 1/2"	20 PCS
	WOOD DOWEL M8 X 25	30 PCS
	WOOD DOWEL M6 X 25	6 PCS
	METAL RUNNER	2 SETS
	SCREW M4 X 12	24 PCS
	HANDLE	2 PCS
	TRUSS HEAD MACHINE M4 X 20	4 PCS
	CORNER BLOCK	4 PCS
	SCREW M3 X 20	4 PCS

TOOLS REQUIRED	SCREW DRIVER	HAMMER
STEP 2		

STEP 2	STEP 3	STEP 4	STEP 5	STEP 6	STEP 7	STEP 8	STEP 9
WOOD DOWEL M8 X 25 DETAIL A	DETAIL A EURO BOLT	SCREW M4 X 12 DETAIL A DETAIL B METAL RUNNER	HOUSING D-12/9.5MM DETAIL A TURN TO LOCK	TRUSS HEAD MACHINE M4 X 20 DETAIL A HANDLE	SCREW M4 X 12 DETAIL A METAL RUNNER	WOOD DOWEL M6 X 25 DETAIL A	WOOD DOWEL M8 X 25 DETAIL A

STEP 10	STEP 11	STEP 12	STEP 13	STEP 14	STEP 15	STEP 16	STEP 17	STEP 18
SCREW #9 X 1 1/2"	HOUSING D-15/12.5MM DETAIL A TURN TO LOCK	SCREW #9 X 1 1/2"	HOUSING D-15/12.5MM DETAIL A TURN TO LOCK	CORNER BLOCK SCREW M3 X 20 DETAIL A	WOOD DOWEL M6 X 25 DETAIL A	WOOD DOWEL M8 X 25 DETAIL A	WOOD DOWEL M6 X 25 DETAIL A	WOOD DOWEL M8 X 25 DETAIL A