

ASSEMBLING INSTRUCTIONS

CAUTION :

THIS ITEM IS MADE OF LAMINATED PARTICLE BOARD AND MEDIUM DENSITY FIBRE BOARD
TO BE ASSEMBLED ON A DRY, SOFT, SMOOTH AND CLEAN SURFACE . DO NOT USE DETERGENT OR CHEMICAL. AVOID DAMP AND SUNLIGHT.

STEP 1	CHECK YOUR HARDWARE	H5366-1A
	EURO BOLT	14 PCS
	HOUSING D:15/12.5MM	14 PCS
	SCREW #9 X 1 1/2"	4 PCS
	WOOD DOWEL M8 X 25	19 PCS
	HANDLE	2 PCS
	TRUSS HEAD MACHINE M4 X 20	4 PCS
	HINGES	4 SETS
	SCREW M3.5 X 14	17 PCS
	DOOR STOPPER	1 PC
	CORNER BLOCK	4 PCS
	SCREW M3 X 20	4 PCS
	ADJUSTABLE SHELF STUD	4 PCS
TOOLS REQUIRED		
	SCREW DRIVER	HAMMER
STEP 2 WOOD DOWEL M8 X 25		
STEP 3 EURO BOLT SCREW M3.5 X 14 TRUSS HEAD MACHINE M4 X 20 DOOR STOPPER HINGES HANDLE		
STEP 4 TRUSS HEAD MACHINE M4 X 20 SCREW M3.5 X 14 HINGES HANDLE		
STEP 5 SCREW #9 X 1 1/2"		
STEP 6 SCREW #9 X 1 1/2"		
STEP 7 	STEP 8 HOUSING D:15/12.5MM DETAIL A TURN TO LOCK	
STEP 9 ADJUSTABLE SHELF STUD DETAIL A	STEP 10 HOUSING D:15/12.5MM DETAIL A TURN TO LOCK	
STEP 11 CORNER BLOCK SCREW M3 X 20 DETAIL A	STEP 12 SCREW M3.5 X 14 DETAIL A	
STEP 13 	STEP 14 	