

ASSEMBLING INSTRUCTIONS

CAUTION :
THIS ITEM IS MADE OF LAMINATED PARTICLE BOARD AND MEDIUM DENSITY FIBRE BOARD
TO BE ASSEMBLED ON A DRY, SOFT, SMOOTH AND CLEAN SURFACE . DO NOT USE DETERGENT OR
CHEMICAL. AVOID DAMP AND SUNLIGHT.

STEP 1	CHECK YOUR HARDWARE	6309-2
	SCREW #9 X 1 1/2"	8 PCS
	SCREW M3.5 X 20	6 PCS
	SCREW M3.5 X 12	9 PCS
	SCREW M3.5 X 14	18 PCS
	SCREW #6 X 1 1/2"	2 PCS
	PAN HEAD SCREW M3.5 X 12	2 PCS
	SCREW M3 X 12	18 PCS
	SCREW M3.5 X 16	6 PCS
	PAN HEAD SCREW #6 X 20	6 PCS
	WOOD DOWEL M6 X 25	10 PCS
	EURO BOLT	4 PCS
	HOUSING D:15/12.5MM	4 PCS
	DOOR STOPPER	6 PCS
	WALL PLUG PLASTIC	2 PCS
	HANDLE	3 PCS
	LEG STUD	4 PCS
	PLASTIC L BRACKET	2 PCS
	STICKER	8 PCS
	SHOE RACK HOLDER	3 SETS

TOOLS REQUIRED

	SCREW DRIVER		HAMMER
---	--------------	---	--------

