



DEL MONTE **H&H**

## ASSEMBLY INSTRUCTION

DRESSOIR

ART. NO. - 46965



FR

Pensez à  
donner ou  
recycler.



Association

ou





Magasin

ou






Déchèterie


<https://quefairemesdechets.fr>



1




2








3


## LED ADAPTOR WITH FOOT SWITCH









# CHANGE STRIP LIGHT



TOUCH AND HOLD : CHANGE THE BRIGHTNESS  
TOUCH SHORT : ON/OFF



# HINGE ADJUSTMENT INSTRUCTION



# CHANGE DIMMER

|                               |                                                               |          |                                                                           |                                                                  |
|-------------------------------|---------------------------------------------------------------|----------|---------------------------------------------------------------------------|------------------------------------------------------------------|
| <p>1</p> <p>REMOVE SCREW</p>  | <p>2</p> <p>MOVE THE YELLOW MARKED CABLE THROUGH THE HOLE</p> | <p>3</p> | <p>4</p> <p>DISCONNECT LED INSIDE DOOR</p>                                | <p>5</p> <p>PUSH THE DIMMER FROM THE INSIDE THROUGH THE HOLE</p> |
| <p>6</p> <p>REMOVE DIMMER</p> | <p>7</p> <p>PUT IN A NEW DIMMER</p>                           | <p>8</p> | <p>9</p> <p>MOVE THE MALE CONNECTOR THROUGH THE HOLE IN THE BACKWAKLL</p> | <p>10</p> <p>CONNECT LED INSIDE DOOR</p>                         |
| <p>11</p> <p>FIX SCREW</p>    | <p>12</p> <h2>LED ADAPTOR WITH FOOT SWITCH</h2>               |          |                                                                           | <p>13</p>                                                        |