

Ax1



Bx1




Cx1



Dx1




Ex4



M6x35mm

Fx8




M6x40mm

Gx12




Φ 6x Φ 17mm

Hx1




4mm

STEP 1




Temporary fix the arm with the key H for an easy way of assembling!

STEP 2



STEP 3



Arm screw might get loose after a while, please check and make tight again.