

DEL MONTE **H&H**

ASSEMBLY INSTRUCTION

LOW BOARD
ART. NO. - 46968



FR

Pensez à
donner ou
recycler.



Association

ou




Magasin

ou






Déchèterie


<https://quefairemesdechets.fr>



1




1X



2X


2





ADJUSTABLE
SLIDING NAILS

3


LED ADAPTOR WITH FOOT SWITCH




CHANGE STRIP LIGHT





DISCONNECT led INSIDE DOOR



LOOSE BOLT




PULL LED STRIP DOWN




REMOVE LED (→)

FIX NEW LED (←)



FIX BOLT




CONNECT led









TOUCH AND HOLD : CHANGE THE BRIGHTNESS

TOUCH SHORT : ON/OFF



HINGE ADJUSTMENT INSTRUCTION



CHANGE DIMMER

