



CAUTION:

To clean use soft, dry cloth. Do not use detergent or chemicals.
Avoid contact with water and direct sunlight.
To be assembled on a soft,dry, clean and smooth surface.

ORDERING REPAIR PARTS

In order to obtain smooth and rapid service when ordering repair parts, please give full attention to the following of PART NUMBER.



NO	DESCRIPTION	QTY
A	LEFT SIDE	O1
B	TOP	O1
C	CENTRE SHELF	O1
D	CENTRE SHELF	O1
E	CENTRE SHELF	O1
F	CENTRE VERTICAL	O1
G	LOWEST SHELF	O1
H	LEG	O2

NO	DESCRIPTION	QTY
I	RIGHT SIDE	O1
J	BACK	O2
K	LEFT SIDE DOOR	O1
L	RIGHT SIDE DOOR	O1
M	MOVABLE SHELF	O3
N	MOVABLE SHELF	O2


COMPLETE SET

ASSEMBLY INSTRUCTION


MODEL: 27301 / SHOE RACK

Before you begin, please follow Assembly Instruction carefully.
Then follow them step by step.



NO	HARDWARE	LIST	QTY
I	JCBW SCREW M6 x 45		18pcs
II	M4 ALLEN KEY		1pc
III	HANDLE & SCREW M3.5 x 30		2sets
IV	AIM HINGES & SCREW M3.5 x 16		6sets
V	CAP SMALL		16pcs
VI	NAIL		60pcs
VII	PVC NAIL WITH PIN		4pcs
VIII	M8 x 30 PLASTIC DOWEL		12pcs
IX	M3.5 x 30 CHIPBOARD SCREW		1pc
X	PVC SHELF SUPPORT		20pcs




STEP 2




STEP 3




STEP 4




STEP 5




STEP 6



STEP 7



STEP 8



STEP 9