

NOW TAKE A SEAT, ENJOY AND PLEASE READ OUR PASSPORT FOR MAINTAINING YOUR SOFA PROPERLY












2

USER MANUAL ELECTRIX RELAX

STANDARD AND ZERO GRAVITY


ELECTRIC RELAX START POSITION




PUSH THE BUTTONS TO MOVE INTO RELAX POSITION AND BACK


STANDARD


ELECTRIC RELAX IN RELAX POSITION




ZERO GRAVITY ELECTRIC RELAX IN RELAX POSITION











1/2/2,5/3 SEATER TWO ARMS (STANDARD LEGS)







USER MANUAL HEADREST

HEADREST CAN BE TURNED MANUALLY IN 6 STEPS


HEADREST IN START POSITION





HEADREST IN UP POSITION



2 / 2,5 / 3 SEATER ONE ARM ELECTRIC










ELEMENTS


1/2/2,5/3 SEATER TWO ARMS (DESIGN LEGS)






1 / 2 / 2,5 / 3 SEATER ONE ARM










ELEMENTS


2 / 2,5 / 3 SEATER ONE ELECTRIC ELEMENT










1/2/2,5/3 SEATER ELECTRIC (DESIGN LEGS)












ELEMENTS


1 / 2 / 2,5 / 3 SEATER NO ARMS






HOCKER








ELEMENTS


1/2/2,5/3 SEATER ELECTRIC (STANDARD LEGS)












OTTOMANE SMALL











OTTOMANE











10